



App Control&Internet of Things



Optional Functions



Body temperature Measure



Video Intercom System

## Walk Through Metal Detector UNX330

### Applications:

- Security Inspection:  
Public Venues, Law Enforcement, Prison, Sports Center,
- Factory Anti-theft:  
Chemical, Mineral, Electronic, Hardware, Plastic Factories
- Education System  
Checking of cheating Aid.

Touch Screen System  
Equipped with 7-inch HD LCD screen (touch function), the operation is become more convenient and intuitive, high-end convenient and more intelligent.



### Technical Parameters:

Parameters	
Detected Object	Contraband including mobile phone and metals
Vertical dimension	2240 × 670 × 850mm
Vertical tunnel size	2000 × 700mm
Package Size	2280 × 700 × 290mm
Humidity	-20℃~65℃
Working Environment	AC90V~240V 50 / 60Hz
Installation Environment	(W)100cm x (L)200cm (no metal in this range)
Power Consumption	20W
Working Frequency	1—100
Weight	NW 67KG GW 75KG

### Functions:

- ★ Multi-zone technology: 33 detection zones, adjust sensitivity of each zone individually.
- ★ Touch screen: 7-inch HDMI LCD touch screen, easy to operate and understand.
- ★ Mobile connection technology: realize mobile APP remote control (optional).
- ★ IP Grade: IP54 superior waterproof performance (optional)
- ★ Self calibration once power on.
- ★ Self diagnostic, it will inform the user when exit the system.
- ★ Start-stop technology: infrared devices with automatic start-stop technology.
- ★ Adjust the alarm sounds arbitrarily.
- ★ Adjust the working frequency automatically or manually.
- ★ Detection Technology: Even detection technology, no blind spot.
- ★ Professional detection process: built in 72 different detection occasions (providing upgrade services).
- ★ Working frequency: Maximum 100 working frequency.
- ★ Security level: 100 security levels.
- ★ Detection sensitivity of each zone: From 0 to 255 level.
- ★ Multi-alarm sounds to choose-to fit different applications.
- ★ Statistics: Record the pass and alarm numbers
- ★ Query function: The system has real-time information query function.
- ★ Intelligent Standby: The system has intelligent standby operation alerts.
- ★ Working Standby: 16 high-brightness LED indicator on.
- ★ Detection speed: more than 60-150 people pass and detect in 1 minute.

Note: The above pictures and parameters for reference only, the actual quotation and sales contract shall prevail

### Detection Zones:

